

CSUEB GBI Bioinformatics, Command Line, and AWS Introduction Report

Flint Mitchell
July 11 - 15, 2022

Abstract

The purpose of this project was to learn the basics of the command line, how to use Amazon Web Services EC2 instances, and to take long and short read sequencing data of a sweet potato chloroplast genome and assemble them together into larger, more useful, annotated contigs.

Methods and Results

- *Downloading the Sequencing Data*

We found subsampled short and long read data from the following research paper:

Zhou C, Duarte T, Silvestre R *et al.* Insights into population structure of East African sweetpotato cultivars from hybrid assembly of chloroplast genomes [version 1; peer review: 2 approved with reservations]. *Gates Open Res* 2018, **2**:41 (<https://doi.org/10.12688/gatesopenres.12856.1>)

We then downloaded this data using the curl command:

```
curl
https://zenodo.org/record/3567224/files/sweet-potato-chloroplast-illumina-reduced.fastq?download=1 > sweet-potato-chloroplast-illumina-reduced.fastq

curl
https://zenodo.org/record/3567224/files/sweet-potato-chloroplast-nanopore-reduced.fastq?download=1 > sweet-potato-chloroplast-nanopore-reduced.fastq
```

After we downloaded the data, we checked to see how many reads we had using the wc command:

```
wc sweet-potato-chloroplast-illumina-reduced.fastq
sweet-potato-chloroplast-nanopore-reduced.fastq
```

From this we learned that we had 62500 illumina short reads and 2000 Oxford Nanopore (ONT) long reads.

- *Checking the Quality of the Data*

In order to look at the length of our nanopore reads and assess the quality of them, we used a program called NanoPlot. The command to do this was:

```
NanoPlot -t 2 --fastq sweet-potato-chloroplast-nanopore-reduced.fastq
```

This command generated the following plot, showing us the quality scores of the reads with given lengths.



According to NanoPlot, our data had the following average read lengths and qualities.

Mean read length	6,664.9
Mean read quality	10.3
Median read length	4,942.0
Median read quality	10.6

- Filtering and Trimming the Data

This data was already filtered and trimmed, but if I needed to filter and trim this data I would use the following program:

```
trim_galore -q 25 SRR1946554_1_4k.fastq.gz
```

- Genome size estimation

We already had an estimate for the size of the sweet potato chloroplast genome at approximately 160kb (160,000 bases). If we wanted to estimate the size of this genome, we could have used a k-mer counting program called jellyfish and the plotting software on Genome Scope (<http://qb.cshl.edu/genomescope/>).

- Assembly

With our 2 datasets, we generated 3 assemblies.

- This first used only the nanopore long-read data.
- The second used only the illumina short-read data.
- The third used the result of the first assembly using the long-reads, and polishing it with the short-read data.

For the first assembly using only long-read data, we used a software called flye. This software takes inputs of the estimated genome size, the fastq file with our reads, and a number of CPU threads to speed up the process. The command I used looked like:

```
flye --genome-size 160000 --nano-raw  
sweet-potato-chloroplast-nanopore-reduced.fastq -t 4 --out-dir  
sweet-potato-chloroplast-ont-assembly-071322
```


Using the cat command on our CLI, we read out the results of this assembly:

```
nt-assembly-071322$ cat assembly_info.txt
```

#seq_name	length	cov.	circ.	repeatmult.	alt_group	graph_path
contig_1	131851	86	N	N	1	* -2,1,2
contig_3	4895223	N	N	1	*	2,3,-2
contig_2	29900140	N	Y	1	*	2

Using the software tool Bandage, we generated a picture of how the contigs above fit together. In order to do this, we used the following command:

```
Bandage image assembly_graph.gfa sweetpotatogfa.png
```



For the second assembly using only short-read illumina data, we used a program called ABySS. The command to run ABySS that we used is:

```
abyss-pe name=spotato-chloroplast-k50-071422 j=2 v=-v k=31  
in="sweet-potato-chloroplast-illumina-reduced.fastq" | tee  
sweet-potato-chloroplast-assembly-stdout.log
```

For the third assembly where we polished our long-read assembly with the short read data, we used a series of programs called BWA, samtools, and pilon. BWA was used to index and align our short reads to our long read assembly. Samtools was used to make the output of BWA more compatible with our computer. Pilon was then used to polish the long-read assembly with the higher quality-score short read data.

First, use the following command:

```
bwa index assembly.fasta
```

Then let's copy the short reads to our current directory:

```
cp ~/seqdata/sweet-potato-chloroplast-illumina-reduced.fastq .
```

Next we have a command that creates the alignment between the short reads and the long-read assembly:

```
bwa mem assembly.fasta  
../../../../seqdata/sweet-potato-chloroplast-illumina-reduced.fastq > aln-se.sam
```

After this we need to convert the output file (which is the `.sam` file) into something that's easier for the computer to read. The SAM file is human-readable and less efficient, whereas the BAM file is in binary:

```
samtools view -S -b aln-se.sam > aln-se.bam
```

Then we have to do some further editing to this BAM file with the following two commands:

```
samtools sort aln-se.bam -o aln-se.sorted.bam
```

and

```
samtools index aln-se.sorted.bam
```

And finally we are ready to do the actual polishing of our long read assembly with the short reads using `pilon`:

```
java -Xmx12G -jar pilon-1.24.jar --genome assembly.fasta --bam  
aln-se.sorted.bam
```

- Assembly Quality

In order to assess the quality of our assemblies, we used a program called QUAST, Quality Assessment Tool. This generates statistics related to the completeness of our assembly.

The command to run QUAST that we used is:

```
quast.py -o nanopore-chloroplast-assembly --est-ref-size 160000 --min-contig  
100 assembly.fasta
```

The outputs of QUAST for the three assemblies were:

For the long-read only assembly using flye:

`nt-assembly-071322nanopore-chloroplast-assembly$ cat report.txt`

All statistics are based on contigs of size ≥ 100 bp, unless otherwise noted (e.g., "# contigs (≥ 0 bp)" and "Total length (≥ 0 bp)" include all contigs).

Assembly	assembly
# contigs (≥ 0 bp)	3
# contigs (≥ 1000 bp)	3
# contigs (≥ 5000 bp)	3
# contigs (≥ 10000 bp)	3
# contigs (≥ 25000 bp)	3
# contigs (≥ 50000 bp)	1
Total length (≥ 0 bp)	210703
Total length (≥ 1000 bp)	210703
Total length (≥ 5000 bp)	210703
Total length (≥ 10000 bp)	210703
Total length (≥ 25000 bp)	210703
Total length (≥ 50000 bp)	131851
# contigs	3
Largest contig	131851
Total length	210703
Estimated reference length	160000
GC (%)	39.17
N50	131851
NG50	131851
N90	29900
NG90	48952
auN	98123.87343796718
auNG	129218.71565625
L50	1
LG50	1
L90	3
LG90	2
# N's per 100 kbp	0.00

The results of QUAST for the short read illumina data only were:

`oplast$ cat report.txt`

All statistics are based on contigs of size ≥ 500 bp, unless otherwise noted (e.g., "# contigs (≥ 0 bp)" and "Total length (≥ 0 bp)" include all contigs).

```

Assembly          spotato-chloroplast-k50-071422-unitigs
# contigs (>= 0 bp)    35
# contigs (>= 1000 bp) 10
# contigs (>= 5000 bp) 7
# contigs (>= 10000 bp) 4
# contigs (>= 25000 bp) 2
# contigs (>= 50000 bp) 0
Total length (>= 0 bp) 131948
Total length (>= 1000 bp) 128852
Total length (>= 5000 bp) 118321
Total length (>= 10000 bp) 99504
Total length (>= 25000 bp) 75047
Total length (>= 50000 bp) 0
# contigs          10
Largest contig     45529
Total length       128852
GC (%)            36.89
N50               29518
N90               5930
auN               26403.68987675783
L50               2
L90               7
# N's per 100 kbp  0.00

```

The results of QUAST for our long-read assembly polished with high quality short reads is:

ubuntu@ip-172-31-56-123:/assembly/sweet-potato-nanopore-ONT/nanopore-chloro-assembly-polished\$ cat report.txt

All statistics are based on contigs of size >= 100 bp, unless otherwise noted (e.g., "# contigs (>= 0 bp)" and "Total length (>= 0 bp)" include all contigs).

```

Assembly          pilon
# contigs (>= 0 bp)    3
# contigs (>= 1000 bp) 3
# contigs (>= 5000 bp) 3
# contigs (>= 10000 bp) 3
# contigs (>= 25000 bp) 3
# contigs (>= 50000 bp) 1
Total length (>= 0 bp) 215274
Total length (>= 1000 bp) 215274
Total length (>= 5000 bp) 215274
Total length (>= 10000 bp) 215274
Total length (>= 25000 bp) 215274
Total length (>= 50000 bp) 135115
# contigs          3
Largest contig     135115
Total length       215274
Estimated reference length 160000
GC (%)            39.03
N50               135115
NG50              135115
N90               30411
NG90              49748
L50               1
LG50              1
L90               3
LG90              2
# N's per 100 kbp  0.00

```

By polishing our long-read assembly with our high quality short reads, the length of our long-read assembly, its longest contig, and its N50 increased in size. This might have to do with the correction of homopolymer deletions in the nanopore data.

This total number of contigs in our long-read assemblies was less than that of our short-read assemblies. This might be because there is repetitive information in the sweet potato chloroplast genome that the short reads cannot determine how long they are. Since we can't determine the length of the repetitive segments, maybe we can't connect the contigs on either side of those and we end up with gaps.

- Annotation

Using our polished assembly, we then used a tool called GeSeq (<https://chlorobox.mpimp-golm.mpg.de/geseq.html>) to annotate it with biological information. After uploading our polished assembly, we checked the boxes for “circular” instead of “linear” and for the Sequence Source, we checked “Plastid.” We can see identifiable biological elements in the results of this annotation, as shown in the following pictures:

